




**BERNARD[®]
CONTROLS**

Invest in Confidence



AT LOGIC v2 RANGE



Start Up Guide

SUG_17011_EN - Ind. F
Art: 5100582

TABLE OF CONTENTS

DEFINITIONS-----	5
1 SAFETY -----	6
2 PACKAGING, STORAGE AND MAINTENANCE-----	6
2.1 Packaging	
2.2 Storage	
2.3 Maintenance	
2.4 Actuator end-of-life	
3 ACTUATOR INSTALLATION -----	9
3.1 Mounting the actuator on the valve	
3.2 Opening the control compartment	
3.3 Electrical wiring	
3.4 Closing the control compartment	
3.5 Wiring the external ground terminal	
4 ACTUATOR CONTROLS-----	17
4.1 Control panel	
4.2 Control modes	
4.3 Local control with the Control panel	
4.4 Local control with the Smartphone application	
4.5 Remote controls	
4.6 Analog Input/Output (OPTION)	
5 COMMISSIONING -----	25
5.1 Setting the display language	
5.2 Valve tags	
5.3 Actuator Commissioning setting	
5.4 Setting the buttons and display	

5.5	Setting Remote commands	
5.6	Setting the Analog Input/Output function (OPTION)	
5.7	Setting the Relays configuration	
5.8	Setting the forced local mode with BC App	
6	OPERATION -----	65
6.1	Emergency manual command	
6.2	Local control operation	
	APPENDIX -----	67
I.	Starting with BC App	
II.	Alarms and Settings menu tree (options not detailed)	
III.	Diagnostic and Alarms list	
IV.	Factory data menu tree	

DEFINITIONS



Tip or info.



Warning requiring a check and/or a compulsory action.



Warning requiring a check and/or a compulsory action on the device because of risks of damages for the device or danger for the staff working on the device.

1 SAFETY

This device complies with current applicable safety standards.

The installation, maintenance, and use of this unit require a skilled and trained personnel.

Please carefully read this whole document before mounting and powering the actuator.

2 PACKAGING, STORAGE AND MAINTENANCE

2.1 Packaging

The AT actuator packaging is comprised of a corrugated, double wall cardboard box strapped on a pallet. For certain non-EU countries or upon request, the pallets are heat treated to the NIMP 15 standard and IPPC-stamped.

This packaging is identical for shipping by road, air or sea, unless otherwise mentioned in the contract.

2.1.1 Check identification sticker

The information on the nameplate sticker on the side of the actuator should match your order.

The QR code on this sticker can be used to identify the actuator.

2.2 Storage

Actuators should be stored under a shelter, in a clean and dry place, and at a stable ambient temperature.



- Avoid placing the actuator directly on the floor.
- Check that the cable entry plugs are correctly tightened.
- Check that the cover screws are correctly tightened to ensure weatherproof sealing of the cover.

AT actuators include electrical components and lubricated gears. If the actuator is incorrectly stored, regardless of its weatherproof enclosure, alterations may occur, such as oxidation, galling, and other.



The heating resistance should be connected to the power supply, especially if the storage place is wet.

What to check before mounting on the valve, after storage

1. Visually check the electrical equipment for traces of corrosion, humidity, etc.
2. Check that there are no oil leaks.
3. Manually operate buttons, selectors, etc., to ensure proper mechanical functionality.
4. Manually operate the actuator in both directions for a couple of turns.

What to check on pre-installed actuators

If you expect a long delay between actuator valve mounting and electrical wiring, visually check that the cable entries and cover are tightly closed.

2.3 Maintenance

All AT actuators feature lifetime lubrication. They require no specific maintenance under the condition that they were correctly commissioned and operated under their intended use.

2.4 Actuator end-of-life

Although Bernard Controls actuators are designed to last, replacement may become necessary over time. If no specific provisions were foreseen in your local guidelines or in your contract, please consult local recyclers to dispose of your actuator.

Recycling and disposal guidelines

Check your local guidelines. Otherwise, we suggest following these general recommendations:

1. Disassemble your actuator and separate and sort the parts.
2. While disassembling, collect greases and oils. These substances are hazardous and must not be released into the environment. The same applies to batteries.
3. Arrange for controlled waste disposal of the disassembled material or for separate recycling according to materials.
4. Observe the regional regulations for waste disposal.

Product disassembly and part sorting

We recommend that the replaced product be disassembled, and that the parts be separated and sorted according to the following categories (if present):

- greases and oils,
- metals: aluminum, copper/brass, zinc, iron/steel, stainless steel, mixed metals,
- plastics,
- batteries,
- electronic scrap: boards, capacitors, etc.

3 ACTUATOR INSTALLATION

3.1 Mounting the actuator on the valve

The actuator should be secured directly to the valve using proper bolts or via a proper interface.

After assembly, the actuator can operate in any position.



However:

- Do not lift or handle the actuator by its handwheel to avoid shaft and gear damage.
- Cable glands must not be oriented upwards (loss of watertightness).
- It is recommended not to position the motor downwards.



If needed, the orientation of the display can be modified to keep a normal reading orientation (see §5.4.3).

3.2 Opening the control compartment


Open the control compartment and remove the cover to wire the actuator.



When opening the compartment, unplug the control panel cable from the main board to avoid damaging it.

How to remove the cover

1. With a 10-mm angled socket wrench or flat-blade screwdriver, unscrew the 4 screws securing the cover to the housing.
2. Pull out the cover along its axis.
3. When the cover plug is accessible, unplug it from the main board.
4. Remove the cover completely.



3.3 Electrical wiring




Do not supply the wires with electrical power before the wiring is finished and the control compartment is closed.

Make sure to cut off the actuator's power supply when opening the control compartment.

3.3.1 Components (with cover open)

AT configuration (AT7 excepted)




- 1 - Terminal block for control
- 2 - Push-on connectors for power
- 3 - External ground terminal
- 4 - Internal ground terminal
- 5 - Cable entries

- 6 - Main board
- 7 - 4-Relay board (OPTION)
- 8 - AI/AO board (OPTION)
- 9 - Bus board (OPTION)
- 10 - Modular reduction gear

The control panel board is attached to the actuator cover.

AT7 configuration



- | | |
|----------------------------------|-----------------------------|
| 1 - Terminal block for control | 6 - Main board |
| 2 - Push-on connectors for power | 7 - 4-Relay board (OPTION) |
| 3 - External ground terminal | 8 - AI/AO board (OPTION) |
| 4 - Internal ground terminal | 9 - Bus board (OPTION) |
| 5 - Cable entries | 10 - Modular reduction gear |


3.3.2 Installing the cable glands

AT configuration (AT7 excepted)

AT actuators can be fitted with 2×M16 & 3×M20 (ISO) / 3×3/4" & 2×1/2" (NPT) cable entries.

AT7 configuration

AT7 actuators can be fitted with 2×M16 & 4×M20 (ISO) / 4×3/4" & 2×1/2" (NPT) cable entries.



How to install the cable glands

For each cable entry used


1. Remove the plug from the cable entry with a 19-mm (M16 or ½" NPT entry) or 23-mm (M20 entry) or 29-mm (¾" NPT) open-end wrench.
2. Separate the sealing nut from its cable gland
3. Screw and tighten the cable gland into the cable entry.
4. Insert the sealing nut on the cable and pass the cable through the cable gland.



Unused entries must be kept closed using plugs as they are part of the components allowing the actuator to be rated with IP68 protection.

3.3.3 Wiring power and control cables

Terminal board



On a side of the electronics assembly there are:


- a screw terminal block to connect command and signaling (A).
- 3 push-on connectors to connect the power supply (B).

Control terminals: 1-36

Power connectors (3Ph/1Ph)

- **3Ph:** L1, L2, L3 with phase correction
- **1Ph:** L (Live), N (Neutral)

Terminal board (with bus)



On a side of the electronics assembly there are:

- a screw terminal block to connect command and signaling (A).
- 3 push-on connectors to connect the power supply (B)
- Line termination resistor switch (C)

Control terminals: 1-36

Power connectors (3Ph/1Ph)

- **3Ph:** L1, L2, L3 with phase correction
- **1Ph:** L (Live), N (Neutral)

Internal ground terminal

The ground terminal is a tapered hole in the plate, located under the terminal board at its left.

How to wire the actuator


The wiring must be done according to the wiring diagram of the actuator.

1. Make sure that the power supply voltage matches the information on the nameplate located on the side of the actuator.
2. Separate the female part of the push-on connector from the male part which is fixed to the board.
3. Using a crimping tool, connect the power supply to the female push-on connectors.
4. Place back the female connectors on the male connectors marked L1, L2 & L3 (3Ph) or L, N (1Ph), depending on the power supply phase.
5. Using a crimping tool, attach the end of the ground cable to the ring lug.

6. Using a 4 mm hex key, secure the ground cable to the ground terminal.
7. Using a 3×0.5 mm flat-blade screwdriver, connect the control and signaling wires to terminals 1 to 36.
8. Tighten the sealing nut on the cable gland when the wiring is complete.
9. Make sure that all cable glands are correctly tightened

3.3.4 Power supply board

The power supply board supplies the actuator with electrical power. The power characteristics are factory set according to the order.



Fuse

There is a fuse at the upper left angle of the board (see picture above).

Its characteristics are as follows:

Fuse current	500 mA	Fuse size (mm) (inches)	6.3×32 ¼"×1-¼"
Voltage rating VAC	500 V	Blow characteristic	Fast acting
Breaking current capacity current AC			1 kA

3.3.5 Relays

The AT Logic is equipped with a Fault relay and 3 signaling relays.

- ➔ See list of Fault relay Alarms in Appendix III. This list cannot be modified.

Customizable relays


Out of the 3 signaling relays, one is customizable. A 4-Relay board can be added as an option (each relay is customizable).

- ➔ To see possible settings and set relays, see §5.7.

3.3.6 Positioner board (OPTION)

The positioner board is assembled on the main board.

It is possible to pick between **mA** and **V** using the small switch at the base of the board.



3.3.7 Heating resistance

Each actuator includes a heating resistance.

As soon as the actuator is installed in the field, it is required to supply the resistance to prevent condensation.



- Immediately put the cover back in place after installation and make sure that its seal is clean. Never leave the actuator's electrical components without their protection cover.

In case of water intrusion:

- Dry the electrical components before putting back the cover.
- Check the electrical insulation.

3.4 Closing the control compartment




Make sure to re-plug the cover wire on the mainboard, otherwise the control panel (see §4.1) will not work.

How to close the electrical compartment

1. Plug the cover wire on the mainboard.
1. Put back the cover, making sure that the screen is correctly oriented for operation, and place it on the housing.
2. With a 10 mm angled socket wrench or flat-blade screwdriver, secure the cover to the housing with the 4 screws.


3.5 Wiring the external ground terminal

1. Crimp the end of the ground cable with a 6 mm ring lug.
2. Using a 5 mm Allen key, fix the ground cable on the housing next to the cable entries (see image opposite).





4 ACTUATOR CONTROLS

4.1 Control panel




The AT LOGIC control panel consists of a **screen**, **2 control knobs**, **1 control selection knob** and **2 configurable LEDs**.

Screen	The screen displays operating status or LOGIC menu
Control selection knob	<p>The control selection knob allows to choose the one of the following control modes:</p> <ul style="list-style-type: none"> • Local: the actuator is controlled using this Control panel, or with a Smartphone via Bluetooth® • Remote: the actuator is controlled remotely • OFF: the controls are deactivated <p>The actuator is set to Local at startup.</p> <p>The control mode can be locked with an optional padlock at the bottom of the control panel.</p>
Knobs	The knobs are used for operation (upper function) or menu navigation (lower function). Once released, these knobs return to the center position.
LEDs	<p>The LEDs indicate the actuator status (CLOSED  or OPEN .</p> <p>Default colors are red for CLOSED and green for OPEN. They can be set according to the country's standard (see §5.4.4).</p> <p>One LED will blink during operation according to the travel direction, and both during Bluetooth® connection.</p>

4.2 Control modes

AT LOGIC can be locally or remotely controlled. The control mode is set using the **Control selection knob** on the control panel. It can be locked using a padlock located at the bottom of the control panel.




Modes are:

- Local mode with the control panel or with Smartphone via Bluetooth® connection
- Remote mode
- Forced local mode when in Remote mode using the Application
➔ This mode first needs to be authorized, see §5.8.

4.3 Local control with the Control panel

4.3.1 Operation




Operation screen indicates...

- **Top:** actuator ID and status icons
 - ⚠: warning / ☒: alarm
 - 📶: Bluetooth® activated
 - 📶: Bluetooth® activated with device connected
 - 🔒: Local command inhibited
- **Center:** current position of the valve, either CLOSED, current percentage between 0 and 100% depending on the travel direction, or OPEN
- **Bottom:** torque level with a torque gauge and an arrow marker to indicate the set torque limit

Knobs use


Minimum pulse duration is 100 ms.



4.3.2 Menu

The Menu screen has 2 main sections:

- Diagnostic and Alarms
- Settings




The Menu screen has 2 main sections:









- **Diagnostic and Alarms**
- **Settings** is used to check or change the actuator's settings: valve tag, password, torque limits, Bluetooth®, etc.

The **Factory data** submenu contains the actuator's characteristics (see Appendix IV).

Settings



How to use the knobs

Left knob	Menu navigation		Right knob
	 ESC	 ↑ (up)	
	 OK	 ↓ (down)	
	Edition		
	 ← (1 digit left)	 - (decrease values)	
	 → (1 digit right)	 + (increase values)	

4.4 Local control with the Smartphone application

Using the Bluetooth® connection of the actuator, it can be operated with the Bernard Controls smartphone application (**BC App**).




- Bluetooth® is active on the actuator at delivery.
- Using the Local controls with BC App requires to have Bluetooth® activated on your smartphone

The application needs to be downloaded and installed on a phone to connect to the actuator by entering an access code.

See Appendix I for preliminary steps.

4.4.1 Operation screen



Before operation



During operation

Status screen indicates:

- **Top:**
 1. Access to main menu
 2. Alternately valve tag and mainboard reference, or control mode
 3. Warnings or alarms (if any)
- **Center:** current position of the valve, either CLOSED, opening percentage between 0 and 100%, or OPEN.

The following functions are used to operate the actuator:

– decreases / + increases the opening target with one or several taps

closes / opens the valve


Only with the Positioner option:

<> drag to define the target position on the dial

- **Bottom:** torque level with a torque gauge

4.4.2 Main menu

You can access the main menu anytime by tapping on .




The Main Menu has 3 main sections:

- Actuator
 - Operate: actuator operation
 - Diagnostic & status: status and alarms used
 - Settings: actuator settings
 - Quit Actuator
- Account: account data
- Assistance: assistance information

4.4.3 Settings screen

From the main menu, you can access the settings.



The Settings Menu has 2 main sections:

- **Top Section:** access to main menu, then valve tag and mainboard reference
- **Settings list:**
 - Valve identification
 - Commissioning of valve
 - Inputs / Outputs / Bus
 - Actuator local settings
 - Access code definition
 - Reset to factory data


4.5 Remote controls

The AT LOGIC remote control system can be operated using an external or internal voltage supply.

The input circuits are fully opto-isolated. The pulse command system requires 4 connecting wires on the client terminal strip: Common, STOP, OPEN, CLOSE. If the STOP local command button is not used, do not connect the STOP wire. The OPEN (or CLOSE) contact must be maintained to operate the actuator.

4.5.1 Single switch control (Dry Contact)

The actuator can be controlled via a single external switch.





➔ The actuator must be configured for the priority type required (open or close), see §5.5.3.

4.5.2 Remote commands



The open and close commands are self-holding (pulse commands) as a standard configuration.

To remove self-holding, remove wire to terminal 7.

Dry contact control	Voltage control
 <p>S - Stop C - Close O - Open</p> <p>A jumper must be fitted across customer terminal 9-10.</p>	 <p>S - Stop C - Close O - Open</p> <p>Remote commands can be used either in AC or DC voltage:</p> <ul style="list-style-type: none"> ➔ Use terminal 10 for voltage from 10 to 60V ➔ Use terminal 11 for voltage from 90 to 250V <p>! It is imperative to comply with the voltage ranges mentioned above, otherwise components will not function or will be damaged. For AUX1 & AUX2 auxiliary commands, these commands can be assigned to specific functions (see §5.5.1).</p>

4.6 Analog Input/Output (OPTION)

4.6.1 Analog signal types

Some actuator configurations can perform control functions in response to a control signal.

Possible signals	Input impedance (ohms)
4-20 mA 0-20 mA 4-12 mA 12-20 mA	260
0-10V	10000

4.6.2 Positioner configuration

To use this function, Positioner mode must be activated:

- using LOGIC menu - see §5.6.1
- using Auxiliary Commands set with Proportional/ON-OFF - see §5.5.1

The input signal is automatically calibrated on the stroke of the actuator (0 - 100%). There is no need to adjust the operating range of the actuator.

The input signal is isolated from the ON/OFF commands and from the remote position signal.

The actuator can still be operated in ON/OFF mode with the Open, Close and Stop commands or using Proportional control. One of the auxiliary commands must be used to select between these 2 control modes.

In the standard configuration, Auxiliary Command is set on Proportional/ON-OFF to allow the control mode to be selected remotely:


- ➔ Proportional = Analog control
- ➔ ON/OFF = ON/OFF control.

➔ For Analog Input/Output settings (e.g. Dead band), see §5.5.

5 COMMISSIONING

This section describes the commissioning steps using the Control panel, except otherwise mentioned.

The commissioning can be done through the App in the menu **Settings > Commissioning of Actuator on valve**.



In order to modify the actuator settings, the control mode must be set to **Local mode**.

Accessing the actuator menu

To change the actuator's settings or check the active warnings and alarms, use the Control Panel or the BC App to access the actuator's menu.



It is your responsibility to set the security of the Local Commands (Control Panel or Smartphone Application) for your process:

- The default position of the **Control selector** button should be on **Remote**
- The **Access Code** of the actuator should have been changed
- The remote command "Local Command Inhibition" (from DCS) should be active

To access the actuator menu, enter the access code.



If you are the end-user:

At the first on-site start, we strongly advise you to modify the default **Bluetooth®** access codes. To proceed to these changes, please follow the 2 following procedures.

Initial access codes are 0000 to check settings or 9000 to modify them.

How to enter the access code with Control panel

1. Turn the left knob to the right and hold.
2. Turn the right knob to the left and to the right.

The following screen appears.



3. Enter the access code
 - a. Set the digit value with ↓ and ↑ on the right knob.
 - b. Select with **OK** on the left knob when the value is right.
 - c. Set the following digit: 9000.





If you validate an incorrect value, choose **ESC** with the left knob to reset it.


- d. Once you have set all digits, confirm with **OK** at the bottom of the screen.

The following screen appears.



How to reset the access codes

1. If the actuator powered ON for more than 10 minutes, switch it OFF and switch it back ON.
2. When on the operation display, hold both the left knob  and the right knob  during 10s.
The following screen appears.




3. Select **YES** then validate with **OK**.
The access codes are now reset to 0000 and 9000 and can be reprogrammed.

How to change the access codes



The Bluetooth® access codes can only be changed using **Read & Write mode**.

1. Go to **Settings > Actuator's Passwords**.
The following screen appears.



2. Choose the correct access code option to change:
 - **Access code to Read & Write**, or
 - **Access code to Read only**

3. Set each digit value with **↓** or **↑** on the right knob and validate with **OK** on the left knob.

Access code to Read & Write

5

6

7

8


Save

4. When all digits are set, select **Save** and validate with **OK** on the left knob.
5. Return to the main menu or quit the settings with several **ESC**.


How to change the access codes with BC App

1. Go to Main Menu
2. Select **Settings > Actuator passwords and security**.

The following screen appears.



3. Select the Password you want to change.



4. Enter your new password and confirm it.
5. Tap on **OK** to validate.

5.1 Setting the display language

How to change the display language

1. Enter the menu, then navigate to **Settings > Language**.
The following screen appears.



2. Select the language with **↓** or **↑** on the right knob then confirm with **OK** on the left knob.
3. Go to **SAVE** with **↓** or **↑** on the right knob then validate with **OK** on the left knob.

5.2 Valve tags

The actuator valve TAG name and its location or process can be set in **Settings > Valve Tags**.

5.2.1 How to change the valve TAG

1. Enter the menu, then go to **Settings > Valve Tags**.

The following screen appears.

Valve Tags

Valve TAG

S844.8

Location or Process

2. Select the **Valve TAG** box.
3. Define the **Valve TAG** with ↓ or ↑ on the right knob.
4. Go to **SAVE** with ↓ or ↑ on the right knob then validate with **OK** on the left knob.

5.2.2 How to change the location or process

1. Enter the menu, then go to **Settings > Valve Tags**

The following screen appears.

Valve Tags

Valve TAG

S844.8

Location or Process

2. Select **Location or Process** box.
3. Define the **Location or Process** with ↓ or ↑ on the right knob.
4. Go to **SAVE** with ↓ or ↑ on the right knob then validate with **OK** on the left knob.


5.3 Actuator Commissioning setting

5.3.1 Setting closing direction

Default setting for closing direction is clockwise. Depending on the application, the closing direction may change.

How to change closing direction

1. Enter the menu and navigate to **Settings > Actuator commissioning > Set closing direction**.



Set closing direction

☒ Clockwise

☐ Counter-clockwise

Save


2. Choose the closing rotation direction required, **Clockwise** or **Counter-clockwise** with ↓ or ↑ on the right knob then confirm with **OK** on the left knob.
3. Go to **SAVE** with ↓ or ↑ on the right knob then validate with **OK** on the left knob.

5.3.2 Setting the closing and opening type of end of travel

This section shows the option for the actuator's end of travel setting in both direction (Open and Close): **Position** or **Torque** can be selected.

How to set the closing and opening type

1. Enter the menu, then go to **Settings > Actuator commissioning > Closing & Opening type**.




2. Select your option with **↓** or **↑** on the right knob then confirm with **OK** on the left knob.
3. Select **Save** then validate with **OK** on the left knob.

5.3.3 Setting the torque limits

This setting allows to set torque limits at the main steps of the travel: at the beginning (**Break**), during the travel (**Run**) and at the end of the travel (**End**).

Limits are:

- In closing direction: Break to Close (**BTC**), Run to Close (**RTC**), End to Close (**ETC**), Tight zone
- In opening direction: Break to Open (**BTO**), Run to Open (**RTO**), End to Open (**ETO**), Tight zone



To ensure unseating, the Break percentage should be superior to the Tight zone percentage.

How to set torque limits


1. Enter the menu, then navigate to **Settings > Actuator Commissioning**.
2. Select **Set torque limits** and validate with **OK** on the left knob.

Commissioning of actuator...




3. Select closing or opening direction and validate with **OK** on the left knob.

The following screen appears.




4. Select the limit to modify with **↓** or **↑** on the right knob then validate with **OK** on the left knob.

The following screen appears.




5. To set the **Break** limits

- Set the 1st digit on **0** or **1** with **↓** or **↑** on the right knob then validate with **OK**



- Set the 2nd & 3rd digits with **↓** or **↑** on the right knob then validate each with **OK**.
The **No limit** checkbox is filled in when the option is selected.
- To set **No limit**, make sure the checkbox is filled in, validate with **OK** and confirm using **OK** again.









To correct the set value, go to the 3rd digit with **↑** then to the previous digits with **ESC** and review **a.** or **b.** sub-steps to set a new value.

When done, go to **Continue** with **↓** then validate with **OK** on the left knob.

The torque limit settings page appears.

6. To set the **Run** limit, the **End** limit, and the **Tight zone**:

Run to Close (RTC)	End to Close (ETC)	Opening & closing zone
40% to 100%  <div style="font-size: 2em; font-weight: bold; margin: 5px;">0</div> <div style="font-size: 2em; font-weight: bold; margin: 5px;">5</div> <div style="font-size: 2em; font-weight: bold; margin: 5px;">0</div> % 	40% to 100%  <div style="font-size: 2em; font-weight: bold; margin: 5px;">1</div> <div style="font-size: 2em; font-weight: bold; margin: 5px;">0</div> <div style="font-size: 2em; font-weight: bold; margin: 5px;">0</div> % 	3% to 20%  <div style="font-size: 2em; font-weight: bold; margin: 5px;">2</div> <div style="font-size: 2em; font-weight: bold; margin: 5px;">0</div> % 
Continue	Continue	Continue

Set each digit value with ↓ or ↑ on the right knob then validate with **OK** on the left knob.

Validate **Continue** with **OK** on the left knob.

7. When all limits are set, select **Save** and validate with **OK** on the left knob.


5.3.4 Setting the overtorque limiter

The overtorque limiter allows to stop the actuator in anticipation of the set torque limit. If the actuator is stopped at the torque limit, the effect of the inertia could lead to an actual torque on the valve seat higher than the limit set.

How to set the overtorque limiter


1. Enter the menu, then navigate to **Settings > Actuator Commissioning**.

The following screen appears.



2. Select **Overtorque Limiter on valve seat**.

The following screen appears.



3. Select **Enable / Disable** then confirm with **OK** on the left knob.
4. Go to **Save** with **↓** or **↑** on the right knob then validate with **OK** on the left knob.


5.3.5 Setting the open and closed positions


The AT LOGIC features a position sensor. To set end positions, the OPEN and CLOSED positions need to be set one after another, depending on the first one set.

How to set CLOSED and OPEN position


1. Enter the menu, then navigate to **Settings > Actuator Commissioning > Set closed position** (depending on your needs).

The following screen appears.





2. Close the valve using the closing knob .
3. When the valve is closed, validate **Save** with **OK** on the left knob.

The following screen appears.



4. Select **Confirm** with **OK** on the left knob.
- The following screen appears.




5. Open the valve using the opening knob .


An indication of stroke angle appears.

The position can be set with **OK** on the left knob at any moment.

However, if the stroke you set is too small, the following error screen appears.




Select **Try again** with **OK** on the left knob and continue to open the valve.



When the correct position is reached, select **Save** with **OK** on the left knob.

The following screen appears.



6. Select **Confirm** with **OK** on the left knob.


Closing and opening positions are set.

➔ Once end positions are set, proceed to an operation in each direction to check the settings.

5.3.6 Setting the speed control (Timer)

Speed control allows to reduce the actuator's operation speed, for instance to protect a pipe from water hammering.

You can set travel sections with reduced opening or closing speed.



The following options are available.

- Beginning of slow-motion zone (opening/closing direction)
- End of slow-motion zone (opening/closing direction)
- Slow-motion duration

Total opening/closing time is the result of slow-motion duration and normal speed duration.

How to set the timer

1. Enter the menu, then navigate to **Settings > Actuator Commissioning > Speed Control (Timer)**.

The following screen appears.

Speed Control (Timer)

Travel section with
reduced opening speed
[From 067% to 000%,
Slowmotion 0012s]
Total opening time [Not
activated]

Travel section with
reduced opening speed
[From 067% to 000%,
Slowmotion 0012s]
Total opening time [Not
activated]

2. Select either opening or closing direction and confirm with **OK** on the left knob.

The following screen is displayed.

In opening direction	In closing direction
Beginning of Slow Motion Zone (opening direction)	Beginning of Slow Motion Zone (closing direction)
067%	030%
End of Slow Motion Zone (opening direction)	End of Slow Motion Zone (closing direction)
099%	000%
Slow motion duration	Slow motion duration
0012s	0017s
Total Opening Time Not Activated	Total Closing Time 33s
Save	Save

3. Select **Beginning of Slow-Motion Zone**.

The following screen appears.

Beginning of Slow Motion ...

0 6 7 %

Continue

4. Set the position in % between Closing (0%) and Opening (100%) and confirm with **Continue**.
5. Select **End of Slow-Motion Zone**.
The following screen appears.


End of Slow Motion Zone (...)

0 9 9 %

Continue

6. Set the position in % between Closing (0%) and Opening (100%) and confirm with **Continue**.
7. Select **Slow motion duration**.
8. The following screen appears.

Slow motion duration



Continue

9. Set the duration then confirm with **Continue**.



The total operating time will be calculated and is shown in the Total Opening Time screen (for total opening or closing time).

If “not activated” is displayed, the slow-motion duration defined is too short.

10. Go to **Save** with ↓ or ↑ on the right knob then validate with **OK** on the left knob.

5.4 Setting the buttons and display


The buttons and display settings can be selected in **Settings > Buttons and display**.

5.4.1 How to change the language

In addition to the **Settings > Language** screen, the language display can be selected in this menu.

1. Enter the menu, then go to **Settings > Buttons and Display**.
The following screen appears.

Buttons and display



2. Select **Language** and validate with **OK** on the left knob.
The following screen appears.

Language

<input checked="" type="radio"/> English
<input type="radio"/> Français
<input type="radio"/> 简体中文
<input type="radio"/> 繁體中文
<input type="radio"/> Deutsch
<input type="radio"/> Nederlands
<input type="radio"/> Español
<input type="radio"/> Italiano
<input type="radio"/> Português
<input type="radio"/> Русский
<input type="radio"/> 한국어
<input type="radio"/> العربية
<input type="radio"/> Polski
<input type="radio"/> Türk
<input type="radio"/> Downloaded Language
SAVE


3. Choose the desired language with ↓ or ↑ on the right knob and confirm with **OK** on the left knob.
4. Go to **SAVE** with ↓ or ↑ on the right knob then validate with **OK** on the left knob.

5.4.2 How to change the units between metric and imperial

The unit of measure can be changed between metric or imperial.


1. Enter the menu, then navigate to **Settings > Buttons and Display**.

The following screen appears.



2. Select **Units** and validate with **OK** on the left knob.

The following screen appears.



3. Choose the appropriate units with **↓** or **↑** on the right knob and validate with **OK** on the left knob.
4. Go to **Save** with **↓** or **↑** on the right knob and confirm with **OK**.

5.4.3 How to change the orientation of your display

The display orientation can be modified according to the physical orientation of your actuator.

1. Enter the menu, then go to **Settings > Buttons and Display**.
The following screen appears.

Buttons and display

Language [English]
Units [Metric]
Screen orientation [0°]
LED color [Red = open]
LED in intermediate position [Yellow LED is OFF]
Button mode [Pulse mode]

2. Select **Screen orientation** and validate with **OK** on the left knob.

The following screen appears.


Screen orientation	
<input checked="" type="radio"/>	0°
<input type="radio"/>	90°
<input type="radio"/>	180°
<input type="radio"/>	270°
Save	

3. Select the rotation angle matching the actuator orientation.



Angle values are counterclockwise.

4. Validate with **OK** on the left knob, then **Save** and confirm.
The following screen appears.



5. Select **YES** then validate with **OK** on the left knob.
The display rotates accordingly.


5.4.4 How to choose green or red LED color for open position

The LED color configuration can be adjusted depending on the local standards.

How to set LEDs configuration

1. Enter the menu, then go to **Settings > Buttons and Display**.

The following screen appears.



2. Go down in the menu to **LED color** and validate with **OK** on the left knob.

The following screen appears.

LED Color
<input checked="" type="radio"/> Green = Open
<input type="radio"/> Red = Open
Save

3. Select the corresponding setting and validate with **OK** on the left knob.

4. Go to **Save** and validate it.


The following screen appears.

LED Color		
Do you want to save changes?		
<table style="width: 100%; border: none;"> <tr> <td style="border: 1px solid black; padding: 5px 20px;">NO</td> <td style="border: 1px solid black; padding: 5px 20px; background-color: black; color: white;">YES</td> </tr> </table>	NO	YES
NO	YES	

5. Select **YES** and validate.


5.4.5 How to activate yellow LEDs for intermediate position

1. Enter the menu, then go to **Settings > Buttons and Display**.
The following screen appears.



2. Go down in the menu to **LED in intermediate position** and validate with **OK** on the left knob.

The following screen appears.



3. Select the appropriate setting then validate with **OK** on the left knob.
4. Got to **Save** and validate.
The confirmation screen appears.
5. Select **YES** and validate.

5.4.6 How to set the button mode


The button mode can be configured in **Setting > Button mode**.

The following modes are available:

- **Pulse mode:** turn and release the knob to send a command.
- **Maintained mode:** turn and hold the knob to send a command. The command will stop when the knob is released.
- **Proportional mode:** turn the knob to define a precise target percentage of opening.


1. Enter the menu and navigate to **Settings > Buttons and Display**.

The following screen appears.



2. Go down in the menu to **Button mode** and validate with **OK** on the left knob.

The following screen appears.



3. Select the desirable format with ↓ or ↑ on the right knob and confirm with **OK** on the left knob.
4. Go to **SAVE** with ↓ or ↑ on the right knob and validate with **OK** on the left knob.

5.5 Setting Remote commands

5.5.1 Setting Auxiliary Remote commands

To set Auxiliary Remote commands, navigate to **Settings > Remote Commands > Auxiliary Remote Commands 1 or 2**.

The following options are available:

- **Local / Remote** option enables remote control or local control from a remote location.
- **Local + Remote / Remote** option enables remote and local control from a remote location.
- **Local command inhibition** option allows a remote command to override local commands, even if Local/Remote selector is on Local on the actuator.
- **Opening inhibition** prevents the actuator from opening.
- **Closing inhibition** prevents the actuator from closing.
- **Proportional / On-Off** allows to control the equipment either with the positioner function (e.g. 4-20 mA), or with Open / Close / Stop controls.

Auxiliary remote command 1

☒ Not assigned

☐ Local / Remote

☐ Local + Remote / Remote

☐ Local command inhibition

☐ Opening inhibition

☐ Closing inhibition

☐ Proportional / On-Off

Continue

5.5.2 Setting Remote Stop command

Only in hardwired control mode (i.e. not in bus mode), remote stop allows to stop the actuator both in normally open and normally closed configurations. Remote stops are performed by opening a contact (whereas the open or close command is made by closing a contact).




The open and close commands have priority over the stop command.

How to set the remote stop command


1. Navigate in the menu to **Settings > Remote Commands**.

The following screen appears.



2. Go down in the menu, select **Remote Stop** and validate with **OK** on the left knob.

The following screen appears.




3. Select the **STOP** mode: **Normally opened** or **Normally closed**.
4. Go down to **Save** and validate with **OK** on the left knob.
The confirmation screen appears.
5. Select **YES** and validate.

5.5.3 Setting Priority for remote commands


Priority allows to reverse the direction of travel when an operation is in progress without having to stop the actuator.

How to set priority for remote command


1. Navigate in the menu to **Settings > Remote commands**.
The following screen appears.



2. Go down in the menu list, select **Priority** and validate with **OK** on the left knob.
The following screen appears.



3. Select the priority action in the list then validate with **OK** on the left knob.
4. Go down to **Save** and validate with **OK** on the left knob.
The following screen appears.



5. Select **YES** and validate.

5.6 Setting the Analog Input/Output function (OPTION)

If you have an optional analog input/output board or double analog input/output board, go to **Settings > Analog input/output** to activate and configure the different necessary functions.

Analog input/output

Position Activation [Disable]
Input Signal Type [4-20mA, 20mA = Valve Open]
Positioner feedback signal [4-20mA, 20mA = Valve Open, 2 wires connection]
Deadband [5.00%]
Position on Loss of Setpoint [Open]
Improved positioning accuracy by self-learning algorithm [NO]

5.6.1 Analog Input/Output - Activating the positioner

If present, the actuator can operate in positioner mode using a proportional command such as a 4-20 mA analog signal.

How to activate the positioner function



If you are using an auxiliary remote command, the positioner function is automatically activated or de-activated depending on the auxiliary command.

1. From the **Analog Input/Output** menu, enter **Positioner Activation**.

The following screen appears.

Positioner Activation
<input type="radio"/> Enable
<input checked="" type="radio"/> Disable
Save

2. Select **Enable** and confirm with **OK** on the left knob.
3. Go to **Save** then validate with **OK** on the left knob.
The confirmation screen appears.
4. Select **YES** then validate with **OK** on the left knob.
The **Analog Input/Output** menu is then displayed.

5.6.2 Setting the Analog Input/Output signal

How to set the Input Signal

1. From the **Analog Input/Output** menu, enter **Input Signal Type**.

The following screen appears.

Input Signal type
Signal Type
4-20 mA
Signal Direction
20 mA = Valve Open
Save

2. For the **Signal Type** and **Signal Direction** settings:

- Select the setting to adjust and validate with **OK** on the left knob.


The corresponding setting screen appears.

Signal Type	Signal Direction
<input checked="" type="radio"/> 4-20 mA	<input checked="" type="radio"/> 20 mA = Valve Open
<input type="radio"/> 4-12 mA	<input type="radio"/> 20 mA = Valve Closed
<input type="radio"/> 12-20 mA	
<input type="radio"/> 0-20 mA or 0-10 V	
Continue	Continue

- Select the desired option and validate with **OK** on the left knob.



If you choose **0-20mA** or **0-10V**, the switch on the positioner board needs to be switched from the **mA** to the **Volt** position.



- The **Continue** button is highlighted, validate with **OK** on the left knob.
- The display goes back to **Input signal type** screen.

3. Navigate to **Save** and validate with **OK** on the left knob.
The confirmation screen appears.
4. Select **YES** then validate with **OK** on the left knob.
The **Analog Input/Output** menu is then displayed.

5.6.3 Setting the Analog Input/Output positioner feedback signal

How to set Positioner Feedback signal

1. From the **Analog Input/Output** menu, enter **Positioner feedback signal**.

The following screen appears.

Positioner feedback signal

Feedback signal type
4-20 mA

Feedback signal direction
20 mA = Valve Open

Feedback signal wiring
2 wires connection

Save

2. For the **Feedback Signal Type**, **Feedback Signal Direction** and **Feedback Signal Wiring** settings:

- Select the setting to adjust and validate with **OK** on the left knob.

The corresponding setting screen appears.

Feedback signal type

☒ 4-20 mA
☐ 4-12 mA
☐ 12-20 mA
☐ 0-20 mA

Continue

Feedback signal direction

☒ 20 mA = Valve Open
☐ 20 mA = Valve Close

Continue

Feedback signal wiring

☒ 2 wires connection
☐ 3 wires connection

Continue

- Select the desired value and validate with **OK** on the left knob.
- The **Continue** button is highlighted, validate with **OK** on the left knob.


The display goes back to **Input signal type** screen.

3. Navigate to **Save** and validate with **OK** on the left knob.
The confirmation screen appears.
4. Select **YES** and validate with **OK** on the left knob.
The **Analog Input/Output** menu is then displayed.



The 0-10V signal can be obtained using a 0-20mA combined with a 500-ohm (or 499 ohm 1%) resistance.

The power supply needs to be 15 to 32V.



5.6.4 Setting the Analog Input/Output dead band

The dead band value represents the range over which the actuator allows the input signal to deviate from the actual actuator position without making any correction. This setting is made at the factory, but it is possible to adjust it.


- ➔ If the dead band is too narrow, the actuator could hunt, moving back and forth in an attempt to reach the input signal value without stopping within the dead band.
- ➔ If the dead band is too wide, positioning operations are less precise.

The default dead band is 1%.

How to set the dead band

1. From the **Analog Input/Output** menu, enter **Deadband**.

The following screen appears.



2. For each digit
 - Select the digit to adjust.
 - Adjust the digit with ↓ or ↑ on the right knob.
 - Validate with **OK** on the left knob.

When the last digit is validated, **Save** is highlighted.

3. Validate with **OK** on the left knob.

The confirmation screen appears.

4. Select **YES** then validate with **OK** on the left knob.

The **Analog Input/Output** menu is then displayed.

5.6.5 Analog Input/Output Fail-Safe position

When a 4-20 mA input signal is used, it is possible to set up a fail-safe position if the input signal is lost.




This function cannot be used with 0-20 mA signals, as the system cannot discern a lost signal from a 0-mA value.

This function is active in the standard configuration and the actuator remains in its position if the input signal is lost.

How to set the Position on Loss of Setpoint

1. From **Analog Input/Output** menu, enter **Position on Loss of Setpoint**.

The following screen appears.



Position on Loss of Setpoint

☒ Open

☐ Close

☐ Stayput

Save

2. Select the desired value and validate with **OK** on the left knob.
3. Navigate to **Save** and validate with **OK** on the left knob.
The confirmation screen appears.
4. Select **YES** and validate with **OK** on the left knob.
The **Analog Input/Output** menu is then displayed.

5.6.6 Analog Input/Output Improved positioning accuracy

It is possible to improve the actuator's positioning accuracy over time with its self-learning algorithm.

How to set the improved positioning accuracy by self-learning algorithm

1. From the **Analog Input/Output** menu, enter **Improved positioning accuracy by self-learning algorithm**.

The following screen appears.

Improved positioning accur...

☒ YES

☐ NO

Save

2. Select YES or NO and validate with **OK** on the left knob.
3. Go to **Save**, then validate with **OK** on the left knob.
The confirmation screen appears.
4. Select **YES** then validate with **OK** on the left knob.
The **Analog Input/Output** menu is then displayed.

5.7 Setting the Relays configuration

There are three signaling relays.

Relays 1 and 2 are non-customizable, and Relay 3 is customizable.


How to set the signaling relays configuration




The following procedure runs through the procedure for the 3 standard relays installed. Apply the same procedure for optional relays.

1. Navigate in the menu to **Settings > Remote feedbacks**.

The following screen appears.



2. To set a signaling relay, select it and validate with **OK** on the left knob.
3. The following screen appears.



4. To set the condition, select the **Contact closed** or **Contact open** option then validate with **OK** on the left knob.
5. Select **Continue** and validate with **OK** on the left knob.
6. For **Signaling relay 1**, the only option is **Valve open**.
For **Signaling relay 2**, the only option is **Valve closed**.

Signalling options	Signalling options
<input checked="" type="checkbox"/> Valve open	<input checked="" type="checkbox"/> Valve closed
Save	Save

For **Signaling relay 3**, select an option in the below list.

- Valve open
- Valve closed
- Torque limiter - Opening direction
- Torque limiter - Closing direction
- Actuator is opening
- Actuator is closing
- Actuator is running
- Intermediate position indication
- OFF mode
- Local mode
- Remote mode
- Stopped in intermediate position
- Motor Thermal Overload
- Jammed Valve
- Phase Loss
- Power ON
- Handwheel action
- Actuator controlled by Fieldbus
- Overtravel
- Relay operated by Fieldbus

7. Several options can be selected by navigating to the option and selecting each one with **OK** on the left knob.

8. Go to **Save** and validate with **OK** on the left knob.

The following screen appears.

Signalling Options

Do you want to save changes?

NO
YES

9. Select **YES** and validate with **OK** on the left knob.

5.8 Setting the forced local mode with BC App

The feature allows you to use BC App to switch from Remote to Local mode without physically switching the position of the selector from Remote to Local.

2 conditions are necessary to use Forced local mode:


- Allowing the switch to Local mode with the actuator button OR Bluetooth
- Switch to Local mode within BC App

5.8.1 Switch Local/Remote Mode


How to allow switch local/remote mode

- Navigate in the menu to **Access code to Read and Write**
- Go to **Settings > Actuator's Passwords**.

The following screen appears.




- Go down in the menu to **Switch Local/Remote Mode** and validate with **OK** on the left knob.
- The following screen appears.



- To allow switch to Local/Remote control with BC App, select **With the Actuator Button OR the Bluetooth** or **With the Actuator Button ONLY**, then validate with **OK** on the left knob.

6. Go to **Save** and validate it.
The following screen appears.




7. Select **YES** and validate with **OK** on the left knob.

5.8.2 Switching to Local control within BC App

You can only proceed to this operation if the **Control selector** is on **Remote** on the actuator and the actuator's **Switch Local/Remote Mode** is set to **Switch to local mode allowed**.


How to switch to Local control with App

1. Navigate to the **Operate** screen.




If the switch is inhibited, an **Info** button replaces the **Edit** button.

2. Tap on **Edit**. The App asks for confirmation.



3. Tap on **Switch to Local Mode**.

Remote mode becomes Local mode.



The actuator can now be operated as if it was set on **Local mode**.



To get back to **Remote mode**, simply tap again on the **Edit** button.

6 OPERATION

6.1 Emergency manual command

AT LOGIC actuators feature a handwheel for emergency operation.

6.1.1 Automatic clutching

All AT LOGIC actuators except AT7 have automatic clutching of the manual control.




Beware, the declutch is automatic. Use the Manual Command only when the electric motor commands are inactive, or the local knob is on **OFF**.

Their handwheels feature a foldable handle allowing to avoid potentially harmful turning protruding parts during electrical operation. This handle can be folded during electrical operation and unfold it if you need to operate the actuator manually.

6.1.2 Manual clutching (AT7 only)

AT7 has a handle to clutch handwheel and operate the actuator manually. Emergency manual command automatically declutches in case of electrical operation.

You can clutch the handwheel by turning upwards the knob below it. In case clutching is difficult, you can ease the clutching by slightly turning the handwheel while turning the knob.



When using the Positioner option, all movement superior to 5% with the handwheel will start an alarm and will prevent electrical operation. To correct this, return to the previous position.

6.2 Local control operation

To use:

- Local control mode with Control panel
➔ see §4.3
- Local control mode with Smartphone
➔ see §4.4
- Forced Local control mode from Remote mode, with Smartphone:
➔ see §5.8 - how to allow modes switch then switch modes, and §4.4 to use Local mode with Smartphone

APPENDIX


I. Starting with BC App

Installing the application




An Internet connection is required on your smartphone.

1. Go to your app store and search for “**Bernard Controls**”.



2. Once found, download and install **BC App**.


Once installed, start the App. Log in or follow the free account creation sequence if it is your first start.




Connecting to the actuator

Once the account is confirmed, your smartphone is ready to connect to the actuators. Connection to the actuators is achieved with Bluetooth®.


1. Start the App and log into your account.
2. Once logged in, the App will start to scan for nearby actuators.
3. If the desired actuator is found, select it.
If not, retry, or scan the actuator QR code on the sticker, or enter its serial number.




>




or



4. Check that you are connected to the correct actuator (the 2 LEDs in front of the actuator should blink and the Bluetooth icon on the screen has between +), then enter the Access code.



>



II. Alarms and Settings menu tree (options not detailed)

Level 1	Level 2	Level 3
System Alarm & Warning		
Settings	Language	
	Valve tags	<ul style="list-style-type: none"> • Valve tag • Location or process
	Actuator commissioning	<ul style="list-style-type: none"> • Set closing direction • Closing & Opening Type • Set torque limits • Overtorque Limiter on valve seat • Set closed position • Set open position • Speed Control (Timer)
	Remote commands	<ul style="list-style-type: none"> • Auxiliary remote command 1 • Auxiliary remote command 2 • Remote stop • Priority
	Remote feedbacks	<ul style="list-style-type: none"> • Signaling relay 1 • Signaling relay 2 • Signaling relay 3

OPTIONS	Analog input/output	<ul style="list-style-type: none"> • Position Activation • Input Signal Type • Positioner feedback signal • Deadband • Position on loss of setpoint • Improved positioning accuracy by self-learning algorithm
	Profibus	<i>Refer to the appropriate guide</i>
	Modbus	<i>Refer to the appropriate guide</i>
	Buttons and display	<ul style="list-style-type: none"> • Language • Units • Screen orientation • LED Color • LED in intermediate position • Button mode
	Actuator's Passwords	<ul style="list-style-type: none"> • Access code to Read only • Access code to Read & Write • Switch Local/Remote Mode • Bluetooth activation
	Factory data <i>(For more detail, see Appendix IV.)</i>	<ul style="list-style-type: none"> • Actuator type • Mechanical features • Motor features • Electrical features • Firmware

III. Diagnostic and Alarms list

System alarms (Fault Relay)	
Alarm	Description
Locked motor in open direction	The motor is immobilized in the opening direction
Locked motor in close direction	The motor is immobilized in the closing direction
Torque sensor fault	The torque sensor is not working properly
Position sensor fault	The position sensor is not working properly
Abnormal rotation direction in Opening	There is an anomaly in the opening direction of rotation
Abnormal rotation direction in Closing	There is an anomaly in the closing direction of rotation
Configuration memory fault	There is an error in the stored configuration data
Lost phase (3-phase motor)	There is a phase missing on the 3-phase supply
Thermal overload	The thermal switch of the motor was tripped
Valve jammed	The maximum torque was reached during operation
Lost signal 4-20mA	The 4-20 mA signal has been lost
Communication fault between main board and HMI	The communication between the main board and the HMI is not working properly
Communication Fieldbus fault	The communication between the main board and the bus board is not working properly
Loss of main power	The main power is not present
Communication between the Main board and the Fieldbus board	The communication between the main board and the bus board is not working properly

Warnings	
Warning	Description
Overtravel	The position overshoot by >5% after the motor cut off
Activity memory fault	There is a fault in the stored activity data
Excessive number of starts	The start-up rate exceeds the average for this actuator class
Auxiliary power supply fault for external circuits	The auxiliary power is not working. The main board has been damaged
Local Button fault	The buttons are not working
Selector Off activated	The selector button is in the OFF position
Selector Local activated	The selector button is in the Local position
Position fault (<-10% and >110%)	The position is outside the range
Auxiliary command 2 internal error	Auxiliary command 2 is in fault. The main board has been damaged.
Actuator hunting action detected	Actuator hunting action detected
Handwheel action	The handwheel has been used since the last motorized movement

IV. Factory data menu tree

Level 1	Level 2
Actuator Type	<ul style="list-style-type: none"> Type Control type Serial number Manufacturing date
Mechanical features	<ul style="list-style-type: none"> Max Torque Output Speed (rpm) Operating time Protection Type Protection Ex Certificate Duty Class Max Temperature Min Temperature Output Flange Environment Corrosivity Lubricant Type Lubricant Quantity
Motor features	<ul style="list-style-type: none"> Supply Voltage (V) Frequency (Hz) Motor speed (rpm) Motor power (kW) Motor Duty Nominal Current (A) Starting Current (A)
Electrical features	<ul style="list-style-type: none"> Wiring Diagram Dimensional Drawing AI/AO Board 4 Extra Relay Board Bus type
Firmware	<ul style="list-style-type: none"> Profibus/Modbus board version (OPTIONS) Main board version HMI board version

BERNARD CONTROLS GROUP

CORPORATE HEADQUARTERS

4 rue d'Arsonval - CS 70091 / 95505 Gonesse CEDEX France

Tel.: +33 (0)1 34 7 71 00 / Fax: +33 (0)1 34 07 71 01 / mail@bernardcontrols.com

CONTACT BY OPERATING AREAS

> AMERICA

NORTH AMERICA

BERNARD CONTROLS UNITED STATES
HOUSTON

inquiry.usa@bernardcontrols.com
Tel. +1 281 578 66 66

SOUTH AMERICA

BERNARD CONTROLS LATIN AMERICA
inquiry.southamerica@bernardcontrols.com
Tel. +1 281 578 66 66

> ASIA

CHINA

BERNARD CONTROLS CHINA &
BERNARD CONTROLS CHINA NUCLEAR
BEIJING
inquiry.china@bernardcontrols.com
Tel. +86 (0) 10 6789 2861

KOREA

BERNARD CONTROLS KOREA
SEOUL
inquiry.korea@bernardcontrols.com
Tel. +82 2 553 6957

SINGAPORE

BERNARD CONTROLS SINGAPORE
SINGAPORE
inquiry.singapore@bernardcontrols.com
Tel. +65 65 654 227

> EUROPE

BELGIUM

BERNARD CONTROLS BENELUX
NIVELLES (BRUSSELS)
inquiry.belgium@bernardcontrols.com
inquiry.holland@bernardcontrols.com
Tel. +32 (0)2 343 41 22

FRANCE

BERNARD CONTROLS FRANCE &
BERNARD CONTROLS NUCLEAR FRANCE
GONESSE (PARIS)
inquiry.france@bernardcontrols.com
Tel. +33 (0)1 34 07 71 00

GERMANY

BERNARD CONTROLS DEUFRA
TROISDORF (KÖLN)
inquiry.germany@bernardcontrols.com
Tel. +49 2241 9834 0

ITALY

BERNARD CONTROLS ITALIA
RHO (MILANO)
inquiry.italy@bernardcontrols.com
Tel. +39 02 931 85 233

RUSSIA

BERNARD CONTROLS RUSSIA
inquiry.russia@bernardcontrols.com
Tel. +33 (0)1 34 07 71 00

SPAIN

BERNARD CONTROLS SPAIN
MADRID
inquiry.spain@bernardcontrols.com
Tel. +34 91 30 41 139

> INDIA, MIDDLE EAST & AFRICA

AFRICA

BERNARD CONTROLS AFRICA
ABIDJAN - IVORY COAST
inquiry.africa@bernardcontrols.com
Tel. + 225 21 34 07 82

INDIA

BERNARD CONTROLS INDIA
inquiry.india@bernardcontrols.com
Tel. +971 4 880 0660

MIDDLE-EAST

BERNARD CONTROLS MIDDLE-EAST
DUBAI - U.A.E.
inquiry.middleeast@bernardcontrols.com



**BERNARD[®]
CONTROLS**

www.bernardcontrols.com